



DÉMARRAGE

INSÉREZ UNE PILE AA DANS LE SENS INDIQUÉ DANS LE COMPARTIMENT À PILE.

RÉGLAGE DE L'HEURE

TOURNEZ LE BOUTON HEURES/MINUTES DANS LE SENS HORAIRE POUR RÉGLER L'HEURE.

RÉGLAGE DE L'ALARME

TOURNEZ LE BOUTON D'ALARME DANS LE SENS ANTIHORAIRE POUR RÉGLER L'ALARME À L'HEURE SOUHAITÉE. POUR ACTIVER L'ALARME, ASSUREZ-VOUS QUE LE BOUTON CHROMÉ SUR LE DESSUS DE L'HORLOGE SOIT VERS LE HAUT.

ARRÊT DE L'ALARME

APPUYEZ SUR LE BOUTON CHROMÉ SUR LE DESSUS DE L'HORLOGE.

REMARQUES :

CETTE HORLOGE DEVRAIT GARDER UNE PRÉCISION JUSQU'À QUELQUES MINUTES PAR ANNÉE. SI L'HEURE SE MET À FLUCTUER, REMPLACEZ LA PILE. RETIREZ LA PILE AVANT DE RANGER L'HORLOGE SI VOUS NE L'UTILISEZ PAS.

START

INSERT ONE AA BATTERY AS INDICATED IN THE BATTERY COMPARTMENT.

TIME SETTING

TURN THE HOUR/MINUTE KNOB CLOCKWISE TO SET THE TIME.

ALARM SETTING

TURN THE ALARM KNOB COUNTERCLOCKWISE TO SET THE ALARM AT THE DESIRED TIME. TO ACTIVATE THE ALARM, MAKE SURE THAT THE CHROME BUTTON ON TOP OF THE CLOCK IS UPWARD.

ALARM STOP

PRESS THE CHROME BUTTON ON TOP OF THE CLOCK.

NOTES:

THIS CLOCK SHOULD BE ACCURATE TO WITHIN A FEW MINUTES A YEAR. SHOULD TIME KEEPING SUDDENLY FLUCTUATE, REPLACE THE BATTERY. REMOVE THE BATTERY BEFORE STORING THE CLOCK IF NOT IN USE.